

FIG. 1




FIG. 2A




FIG. 2B




FIG. 3




FIG. 4

	400			404	408	412
A	PLAY	REVIEW	LISTEN TO	NEW	MESSAGES	11
B	PLAY	REVIEW	LISTEN TO	SAVED	MESSAGES	12
C	DELETE	ERASE		MESSAGE		337
D	SAVE			MESSAGE		339
E	NEXT	SKIP		MESSAGE		#
F	REPEAT	REPLAY		MESSAGE		334
G	ENVELOPE			INFORMATION		335
H	FORWARD			MESSAGE		336
I	RECORD			a	REPLY	338
J	RECORD			a	NEW MESSAGE	2
K				OPTIONS		0
L				MARK IT	URGENT	2
M					CONFIRMATION	3
N				MARK IT	PRIVATE	1
O				SEND	MESSAGE	#
P	MAIN MENU					33#
Q	CANCEL	FINISHED				*
R	POUND					#
S	STAR					*
T	GOODBYE	HANG-UP	EXIT			***
U	ANY 4-DIGIT NUMBER- i.e. MAILBOX OR EXT.					4 DIGIT NUMBER

09917576-110204